

Sehr geehrte Kundin, sehr geehrter Kunde,
wir freuen uns, dass Sie sich für dieses **Moskitonetz für Fenster** entschieden haben. Lesen Sie vor dem ersten Gebrauch des Produktes die Gebrauchsanleitung sorgfältig durch und bewahren Sie diese gut auf. Sollten Sie Fragen haben, kontaktieren Sie den Kundenservice über unsere Website:

www.ds-group.de/kundenservice

Wichtige Hinweise

- Das Produkt eignet sich als Insektenschutz zum Anbringen an Fenstern. Es ist **nicht** zum Anbringen an Türen geeignet.
- Das Produkt ist für den privaten Gebrauch, nicht für eine gewerbliche Nutzung bestimmt.
- Das Produkt nur für den angegebenen Zweck und nur wie in der Gebrauchsanleitung beschrieben benutzen. Jede weitere Verwendung gilt als bestimmungswidrig.
- Verpackungsmaterial von Kindern und Tieren fernhalten. Es besteht Erstickungsgefahr!
- Das Produkt ist **kein** Spielzeug! Kinder müssen beaufsichtigt werden, um sicherzustellen, dass sie nicht mit dem Produkt spielen.
- Nur Original-Zubehörteile des Herstellers verwenden, um die Funktionsweise des Produktes nicht zu beeinträchtigen und eventuelle Schäden zu verhindern.
- Zum Reinigen des Produktes keine ätzenden oder scheuernden Reinigungsmittel verwenden. Das Moskitonetz bei Bedarf mit einem feuchten Tuch und ggf. mildem Reinigungsmittel abwischen.
- Das Produkt bei Nichtgebrauch trocken und vor Kindern und Tieren geschützt aufbewahren.

Lieferumfang

- 1x Moskitonetz
- 1x Klettband, selbstklebend
(Länge ca. 4,8 m / 5,6 m / 6,6 m je nach ArtNr.)
- 1x Zuschneider
- 1x Presswerkzeug
- 1x Gebrauchsanleitung

Den Lieferumfang auf Vollständigkeit und die Bestandteile auf Transportschäden überprüfen. Bei Schäden nicht verwenden, sondern den Kundenservice kontaktieren.

Produktdaten

Artikelnummer:	10400	15662	15667	15668	15669	15670
Farbe:	schwarz	weiß	weiß	schwarz	weiß	schwarz
Maße:	130 x 150 cm	110 x 130 cm	150 x 180 cm			


ID: Z 10400_15662_15667_15668_15669_15670 M DS V2 0125 as

Befestigung

Beachten!

- Der Fensterrahmen muss mindestens 10 mm breit sein, damit das Klettband ideal angebracht werden kann.
- Während des Anbringens **nicht** die Klebeseite des Klettbandes berühren, um die Haftleistung nicht zu verringern.
- Nach dem Anbringen des Klettbandes sollte das Moskitonetz ca. 24 Stunden lang nicht mehr vom Klettband abgenommen werden, damit der Kleber aushärten kann.

Tipp: Das Klettband am Abend anbringen und den Kleber über Nacht aushärten lassen.



1. Den Fensterrahmen reinigen. Er muss frei von Fett, Staub und Schmutz sowie trocken sein, damit das Klettband möglichst gut haftet.
2. Die Schutzfolie vom Klettband abziehen, das Klettband in den Fensterrahmen kleben und andrücken.
3. Das Moskitonetz auf das Klettband drücken. Darauf achten, dass das Moskitonetz straff sitzt und keine Falten schlägt.
4. Die Überstände am Moskitonetz zurechtschneiden (**Bild A**).
5. Die Kanten mit dem Presswerkzeug feststreichen (**Bild B**).

Entsorgung



Das Verpackungsmaterial und das Produkt umweltgerecht entsorgen und der Wertstoffsammlung zuführen.

DS Produkte GmbH, Stormarnring 14,
22145 Stapelfeld, Deutschland

Kundenservice: Am Heisterbusch 1, 19258 Gallin, Deutschland

☎ +49 38851 314650 *) • kundenservice@dspro.de

*) Anruf in das deutsche Festnetz zum Tarif Ihres Anbieters.

Alle Rechte vorbehalten.

Dear Customer,

We are delighted that you have chosen this **mosquito net for a window**. Before using the product for the first time, please read through the operating instructions carefully and store them in a safe place. If you have any questions, contact the customer service department via our website:

www.ds-group.de/kundenservice

Important Notices

- The product can be used to provide protection from insects when it is attached to windows. It is **not** suitable for attachment to doors.
- The product is for personal use only and is not intended for commercial applications.
- Use the product only for the intended purpose and as described in the operating instructions. Any other use is deemed to be improper.
- Keep the packaging material away from children and animals. There is a danger of suffocation!
- The product is **not** a toy! Children must be supervised in order to ensure that they do not play with the product.
- Use only original accessories from the manufacturer in order to guarantee that there is no interference that may prevent the product from working and to avoid possible damage.
- Do not use any caustic or abrasive cleaning agents to clean the product. If necessary, wipe the mosquito net with a damp cloth and mild cleaning agent if required.
- Store the product in a dry place out of the reach of children and animals when it is not being used.

Items Supplied

- 1x mosquito net
- 1x hook-and-loop fastener tape, self-adhesive (length approx. 4.8 m / 5.6 m / 6.6 m depending on article number)
- 1x cutter
- 1x press tool
- 1x operating instructions

Check the items supplied for completeness and the components for transport damage. If you find any damage, do not use the product but contact our customer service department.

Product Data

Article number:	10400	15662	15667	15668	15669	15670
Colour:	black	white	white	black	white	black
Dimensions:	130 x 150 cm		110 x 130 cm		150 x 180 cm	



ID: Z 10400_15662_15667_15668_15669_15670 M DS V2 0125 as

Attachment

Please Note!

- The window frame must be at least 10 mm wide to allow the hook-and-loop fastener tape to be attached properly.
- Do **not** touch the sticky side of the hook-and-loop fastener tape while attaching it so that you do not reduce the adhesive strength.
- After attaching the hook-and-loop fastener tape, the mosquito net should not be detached from the hook-and-loop fastener tape for around 24 hours so that the adhesive can set.

Tip: Attach the hook-and-loop fastener tape in the evening and allow the adhesive to set overnight.



1. Clean the window frame. It must be free of grease, dust and dirt and be dry so that the hook-and-loop fastener tape can stick as well as possible.
2. Peel the protective film off the hook-and-loop fastener tape, stick the tape in the window frame and press it on firmly.
3. Press the mosquito net onto the hook-and-loop fastener tape. Make sure that the mosquito net is taut and does not have any creases in it.
4. Cut off any overhanging bits from the mosquito net (**Picture A**).
5. Smooth down the edges with the press tool (**Picture B**).

Disposal



Dispose of the packaging material and the product in an environmentally friendly manner so that they can be recycled.

DS Produkte GmbH, Stormarnring 14,
22145 Stapelfeld, Germany

Customer Service: Am Heisterbusch 1, 19258 Gallin, Germany

(☎ +49 38851 314650 *) • kundenservice@dspro.de

*) Calls to German landlines are subject to your provider's charges.

All rights reserved.