

HARDTWERK

Hinweise zum Gebrauch 15880

DEUTSCH

Diese Sägekette erfüllt die Rückschlagleistungsanforderungen von ANSI B175.1-2012.

Die Sägekette mit geringem Rückschlag erfüllt die Rückschlagleistungsanforderungen der Norm CSA Z62.3.

Symbole



Allgemeines Gebotszeichen



Handschutz benutzen



Gebrauchsanweisung beachten



Augenschutz benutzen



Maske benutzen



Gehörschutz benutzen

Sicherheitshinweise


- **Zur Montage/Demontage der Sägekette in jedem Fall die Bedienungsanleitung der Kettensäge überprüfen. Je nach Modell kann sich der Prozess unterscheiden.**

- Die Kettensäge in eine normale Arbeitsposition bringen.
- Stets darauf achten, dass die Sägekette in der Führungsnut der Schiene liegt.
- Stets auf die richtige Laufrichtung achten und, wenn nötig, die Kettenspannungsschrauben drehen.
- Insbesondere bei neuen Sägeketten ist anfangs mit erhöhter Ausweitung zu rechnen.

Daher vor Arbeitsbeginn und während des Sägens **regelmäßig alle 10 Minuten die Kettenspannung überprüfen**. Die Sägekette ist richtig gespannt, wenn sie in der Mitte um ca. 3–4 mm angehoben werden kann.

- Die Sägekette muss während des Betriebs gleichmäßig geschmiert werden. **Niemals ohne Kettenschmierung arbeiten.** Die Schneidgarnitur wird sonst innerhalb kürzester Zeit stark beschädigt. Für genaue Anweisungen zum Füllen des Öltanks die **Bedienungsanleitung der Kettensäge lesen**.
- ‚Rückschlag‘ ist das plötzliche und ruckartige Hoch- und Zurückschlagen der Kettensäge. Dieses unkontrollierbare Verhalten von Motorsägen führt häufig zu schweren Unfällen, insbesondere im Kopf- und Gesichtsbereich.

Daher unbedingt beachten: Niemals mit loser Kettenspannung und stumpfer Kette sägen; eine unsachgemäß geschärfte Kette erhöht die Rückschlaggefahr; **niemals oberhalb der Schulter sägen.**



HARDTWERK

Instructions for Use

15880

ENGLISH

This saw chain meets the kickback performance requirements of ANSI B175.1-2012.

The low kickback saw chain meets the kickback performance requirements of CSA Standard Z62.3.

Symbols



General mandatory action sign



Wear protective gloves



Refer to instruction manual



Wear eye protection



Wear a mask



Wear ear protection

Safety Notices

- For assembling/disassembling the saw chain, always check the chainsaw's instruction manual. The process may vary depending on the model.
- Bring the chainsaw into a normal working position.
- Always ensure that the saw chain is positioned in the guide groove of the bar.
- Always ensure the correct direction of running and, if necessary, turn the chain tension screws.
- Especially with new saw chains, increased expansion is to be expected initially. Therefore, before starting work and during sawing, **regularly check the chain tension every 10 minutes**. The saw chain is correctly tensioned when it can be raised by approximately 3–4 mm in the middle.
- The saw chain must be lubricated evenly during operation. **Never operate without chain lubrication**. Otherwise the cutting set will be severely damaged within a very short time.

For detailed instructions on filling the oil tank, **read the chainsaw's instruction manual**.

- 'Kickback' is the sudden and jerky up and back kick of the chainsaw. This uncontrollable behavior of chainsaws often leads to serious accidents, especially in the head and face area.

Therefore, please note the following: Never saw with a loose chain tension or a blunt chain; an improperly sharpened chain increases the risk of kickback; **never saw above shoulder height.**